



1390 Firestone Parkway Akron, Ohio 44301 1-800-772-3452 sales@apvcoatings.com
www.apvcoatings.com

**APV MIXING INSTRUCTIONS
FOR PREPARING
B-100, B-200, M-1, M-7, M-8**

PROPORTIONS FOR MASKING

127g B-100/B-200	225g M-1
127g B-100/B-200	300g M-7
127g B-100/B-200	250g M-8

PROCESSING

Apply two (2) dips of each and dry for 10 minutes at 250-300°F between dips.
Final bake after all dips applied is 30-45 minutes at 250-300°F.